

DS-305W – VESA Bracket Installation

Step 1 – Remove Cover from Monitor Stand

Locate handle at the top of the Monitor Stand and remove the silver plastic cover. You can easily pry the cover up by inserting a sharp tool or knife blade just under an edge. By removing the cover you will reveal 4 screws.



Step 2 – Remove Handle from Monitor Stand

Using a screw driver remove the 4 screws which hold the handle in place. Remove the handle by lifting straight up. This will reveal the hinged bracket which holds the monitor in place.



Step 3 – Remove Monitor from Stand

You can now remove the Monitor from the stand base by lifting it straight up. The Stand base can be set aside and the monitor laid flat on a smooth surface. Remember to protect the glass to avoid scratches or other damage.



Step 4 – Remove Metal Hinge from the Monitor

Using a screw driver remove the 4 screws which hold the hinge to the back of the Monitor. Lift the hinge off and set aside. Retain screws for attaching the VESA Bracket.



Step 5 – Attach VESA Bracket to the Monitor

Using the 4 screws from the previous step, attached the new VESA Bracket to the back of your monitor. You are now ready to mount your Monitor to a third party stand. Follow manufacturer's directions carefully and ensure weight restrictions are observed.



For Questions or Assistance please contact DoubleSight Support at 888.897.8869